

BULL WARMER

Blue Air

Commercial Refrigeration Inc
Gardena California

USER'S MANUAL

Precautions

- Please read instructions before using this appliance.
- When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock and injury.
- Clean machine thoroughly before and after each use following the cleaning instructions provided below.

Preparation

- Set the unit on a flat surface.
- Install bulbs with the appropriate wattage rating as indicated on the warmer.
- If unit fails to work properly when first operated, call Blue Air customer service at 1-866-677-8500

Electrical Requirements

- Plug warmer into a grounded outlet with correct voltage and sufficient power capacity.
- Refer to the product label on the warmer for voltage and wattage requirements.

Safety Instructions

- **Warning!** All power must be disconnected at power source before any service procedure is performed.
- This appliance is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Keep combustible materials, such as drapes and other furnishings, away from appliance.
- Extreme caution is necessary when any appliance is used by or near children and whenever the appliance is left unattended.
- Always unplug appliance when not in use and before cleaning, adjusting or maintaining this machine. To disconnect appliance, turn switch off and remove plug from power source.
- Do not operate any appliance with a damaged cord or plug, after the appliance malfunctions, has been dropped, or damaged.
- Return appliance to an authorized service facility for examination, electrical or mechanical adjustment, or repair.
- Do not use outdoors. This appliance is not intended for wet or moist locations. Never locate appliance where it may fall into water.
- Connect to properly grounded outlets only. Avoid the use of extension cords. Do not run cord under carpeting, runners, or the like. Arrange cord away from traffic area and where it will not create a trip hazard.
- This appliance is equipped with a power cord with a three-blade plug. Plug ONLY into a matching three-blade outlet. DO NOT cut or break off the third blade or attempt to use with a two-blade extension cord.
- To prevent a possible fire, it is recommended that the unit is placed on a non-combustible surface.
- This appliance has electrical parts. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.

Operation

- Plug cord into grounded electrical outlet of the correct voltage. Electrical shock can occur if appliance is not grounded.
- Place food products in a pan, located directly under the bulbs for best results.
- Turn unit off when not in use.
- To disconnect appliance, turn switch off and remove plug from power source.

Cleaning


Note : Proper maintenance plays an important part in the life span and functioning of the warmer.

- Unplug the cord and let warmer cool before cleaning or moving.
- This unit can be cleaned with a damp sponge and mild soap. Rinse with clean water and wipe dry.
- **Do not immerse in water or other liquid.** Do not clean with a water jet.

Service Instruction

Repair: to avoid serious injury or damage, do not repair the warmer or replace a damaged power cord yourself.
Repairs must be coordinated through: Blue Air customer service at 1-866-677-8500

Assembly Instructions



	Part Name	Quantity	Details
A	Frame A	1	Bottom Frame
B	Frame B	1	Connector Frame
C	Frame C	1	Frame for sliding
D	Ass'y Head	1	Lamp unit
1	Screw	2	For assembling A & B
2	Adjust Screw	1	For adjusting Height Level
3	Screw	1	For assembling C & D
4	Power Switch	1	Power ON & OFF

Blue Air Commercial Refrigeration Inc

15001 S. Broadway St., Gardena, CA 90248

Phone: 310-808-0102 Fax: 310-808-0242

Toll Free: 1-866-677-8500

www.blueairinc.com